

AUTOMATE®

Magnetic Charging Accessories

Easily charge your Automate shades with the Magnetic Charging Accessories. Simply snap the magnetic charging cable in place and pull off when fully charged.



Magnetic Removal

Removal of the magnet is a simple pull to disconnect.



No Ladder Required

Eliminates the need for a ladder to access the charging port.



Magnetic Swap

Magnetic connector self-locates making it easy to snap into place.



7 YEAR WARRANTY

ARC

ARC® (Automate Radio Communication) is Rollease Acmeda's proprietary technology utilizing 433MHz radio communication with bi-directional feedback that brings Automate motorized shading systems together.

A Division of Rollease Acmeda

Product Specifications

Part #: MT03-0301-069040 5V MAGNETIC TYPE C KIT 1 X CABLE 1 X USB CONNECTOR
 Part #: MT03-0301-069041 5V MAGNETIC TYPE C KIT 1 X CABLE 5 X USB CONNECTOR
 Part #: MT03-0301-069042 5V MAGNETIC TYPE C KIT 25 X USB CONNECTOR

	Magnetic Cable	Magnetic Connector (USB C)
Vmax	5V	
Imax	2A	
Charging Indicator	Blue LED	
Weight	0.5 oz	0.30 oz

Charging Process



1. Connect the Magnetic Tip to the motor head




2. Check if the Green LED on the motor is blinking (blinking equals charging)



Dimensions

NOTE: For best experience, ensure that the motor is installed with the charging port facing downwards.



Compatible Products



USB Wall Charger 5V



Square Rechargeable Battery Pack