



## Alexa Quick Start Guide


## **GETTING STARTED:**

Before connecting to Alexa, please ensure your SHC Pulse PRO Hub and motorized shades have been setup and are working from within the Smart Home Collection app.

You will also need a Matter-compatible, Alexa hub/smart speaker already linked to your Alexa account.

To control shades with Alexa, you will need the following:


- 1. SHC Pulse PRO Hub that has been set up.
- 2. Working shades within the Smart Home Collection app.
- 3. Alexa app and Amazon account.
- 4. A Matter-compatible hub/smart speaker set up.
- 1. In the **Alexa** app, open the **Devices** page and then select the **+** in the upper right corner. Then select **Add Device**.



**2.** Select the option to add a **Hub** and then select the **Matter** option.

Which device would you like to set up?






**3.** Scan the **Matter** QR code found on the bottom of the **SHC Pulse Pro Hub**.






**SUPPORT RESOUCES:** For further assistance, contact your retailer, or visit our website at <a href="https://www.budgetblinds.com">www.budgetblinds.com</a>.


**4.** Choose one shade at a time, then select **Set Up Device** to add it.




**5.** Select **Done** to add that shade to your account. Repeat for each of the shades.



**6.** Once added, you'll see the shades on the **Devices** page; you can control them from here.



- 7. Test voice commands. Example commands:
  - "Alexa, open kitchen shade"
  - "Alexa, close den blind"
  - "Alexa, activate bedtime routine"



"Alexa, set bedroom shade to 22%"



## Alexa Routines:

Please note that **Rooms**, **Scenes**, and **Timers** set in the **Smart Home Collection App** do not carry over to Alexa. **Routines** can be created in Alexa to achieve similar functionality. For more details, visit **alexa.com** and search for **Routines**.